














3001046  
Dalby Cabinet, black  
with glass door



 ① x26 spare:2	 ② x1 Ø6*30mm	 ③ x1 Ø12*0.8mm	 ④ x1 Ø4*6mm	 ⑤ x1 Ø9*0.8mm
 ⑥ x1	 ⑦ x4 spare:2	 ⑧ x4	 ⑨ x2	 ⑩ x2 Ø4*60mm





( 1 ) - Attach (A) & (H) to (E) as below shown.

Make sure the holes are nearest to outside otherwise will affect door assembling.






The plastic foot cover face down


( 2 ) - Attach (8) to (E) as below shown.





( 3 ) - Attach (B) to (A) & (E) as below shown.





( 4 ) - Attach (F) to (A) & (B) & (E) as below shown.







(5) - Attach (D) to (A) as below shown.






(6) - Attach (G) & (I) to pre-assembled unit as below shown.




(7) - Attach (6) to (C) as below shown.




(8) - Attach (2) & (3) to pre-assembled unit as below shown.



(9) - Attach (C) to pre-assembled unit as below shown.



(10)



Gaps may appear between the top of the doors and the frame if the item is not on level ground; use the plastic foot cover to level.

(11)

