

ASSEMBLY INSTRUCTIONS


Step 1: Insert the axle into the head and join the head eyes with the neck ring.



Step 2: Push the body eyes with the bolts.




Step 3: Connect the head to the body.



Step 4: Connect the motor connecting rod to the metal surface of head.



Step 5: Assembly complete.



Step 6: Use the ground hooks to fix the deer's feet to the ground, if necessary.



Swing link
frame
motor