

15min



(D) Montageanleitung

(NL) Handleiding voor de montage

(TR) Montaj talimatı

(F) Notice de montage

(CZ) Montážní návod

(GB) Assembly instructions

(HU) Szerelési útmutató




(PL) Instrukcja montażu

(RU) Инструкция по монтажу


(IT) Istruzioni di montaggio

(SK) Návod na montáž


(RO) Instrucțiuni de montaj



x1




x1




x1






x2








x2







0-6



I









Service • Assistenza • Dienstverlening • Serwis •
 Servis • Szerviz • Сервисная служба

Name • Nom • Nome • Naam •
 Nazwa • Jméno • Název • Név •
 Denumire • Isim • Название


MELVA R

Nr • No. • N° • Номер • Č • Sz

Type • Tipo • Típus • Typ •
 Тип • Тір




A




x...

B



x...

C



x...

D



x...

E



x...