







USER'S MANUAL
MIRABEAU-43768/43769/43770



Hardware List



M8x45mm

A

4PCS

M8

E

2PCS

ø8

F

4PCS

M8x45mm

A

8PCS

M8

E

4PCS

ø8

F

8PCS

Please note the distinction between parts 12 and 13.

M6x50mm

B

4PCS

ø8

F

4PCS

M6x15mm

G

8PCS

M6x50mm

B

4PCS

ø8

F

4PCS

M6x50mm


B

4PCS


ø8

F

4PCS




11




12



10/10



9



10



9/10