
















Assembly Instruction Sheet


FR18839-32

CAUTION: Because of the edges of some parts before assembly may be sharp, please handle unassembled parts carefully.




Parts List	Qty
A 	1
B 	1
C 	1
D  BIG	1
E 	3
F 	3
G 	3
H 	3
I 	1
J 	1
K  SMALL	1
L 	4
M 	1
N 	1

1




2




Never wave or bump the product fiercely
Never wipe with damp cloth or hard things.
Stock in door after cleaning when not used.

Assembly Instruction Sheet

3




4




Never wave or bump the product fiercely
Never wipe with damp cloth or hard things.
Stock in door after cleaning when not used.

Assembly Instruction Sheet

5



6



Never wave or bump the product fiercely
Never wipe with damp cloth or hard things.
Stock in door after cleaning when not used.