



ASSEMBLY INSTRUCTION/MONTAGEANLEITUNG

139306 / 139307 / 139308 / 139309 / 139310 / 139311



A x14pcs



B x6pcs



C x1pc




D x12pcs



E x20pcs



F x24pcs




G x24pcs



H x24pcs



I x4pcs



J x2pcs



K x4pcs




L x4pcs




M


x2pcs



1 x1pc



2 x1pc



3 x1pc




4 x1pc




5 x1pc




6 x1pc




7 x1pc




8 x1pc



9 x1pc



10 x1pc



11 x2pcs



12 x1pc



13 x1pc



14 x2pcs



15 x2pcs



16 x4pcs



17 x4pcs



18 x4pcs



19 x2pcs




20 x2pcs




21 x2pcs




22 x2pcs



23 x6pcs




5




6

D x 12




7 X2

F x 8
G x 8
H x 8




8 X2

F x 8
G x 8
H x 8




9 X2


F x 8
G x 8
H x 8



10




11



12

E x 20



13

K x 4
L x 4
M x 2

