




WESTMANN

MONTAGEANLEITUNG

Hochbeet Bloomia

WMHPS-S1085E






**BEI FRAGEN, KONTAKTIEREN SIE
UNSEREN KUNDENSERVICE:**




50NRTH GmbH
Straßburgstraße 14-16
D-54516 Wittlich

service@50NRTH.com
+49 (0) 6571 95117-0




30Min


Ax1




Bx1




Cx4




Dx2




Ex4



Fx1




Gx2




Hx1




Ix1




Jx1




Kx1




Lx1




Mx1




Nx1




Ox1




Wx2




Xx2



Px4




Qx61




M4x10mm

Rx57




$\varnothing 4 \times \varnothing 12 \times 1 \text{ mm}$

Sx4




M8x14mm

Tx2




$\varnothing 6.2 \times \varnothing 9 \times 2 \text{ mm}$


Ux2




Vx1




STEP1





STEP1-3




STEP1-4




STEP2





STEP3




STEP3-1







STEP3-2




STEP3-3




STEP4




STEP5





STEP5-1



STEP5-2






STEP5-3






**Qx15
Rx15**





STEP6



STEP7





STEP8



Qx8
Rx8

STEP9





Tx1


Tx1

L

STEP10



STEP11





Ex4

Rx8
Qx10

Xx2


Wx2

Px4



MAX 15mm

STEP12



Durch Drehen dieses
2-Positionen-Reglers im
Uhrzeigersinn oder gegen den
Uhrzeigersinn
können Sie die Festigkeit des
Türverschlusses anpassen.

(Einstellbereich: im Uhrzeigersinn 360°
gegen den Uhrzeigersinn 180°)

